Site Name: Post office distribution centre/ Angerstein sites Site Address: Charlton Area (ha): 3.35 **Current Use:** Post office **Proposed Use:** N/A Vulnerability Unknown Classification: **Tidal Source:** Flood Zone 3 Flood Zone 3b **Area Benefiting from Defences:** Flood Zone 1 Flood Zone 2 (<0.1% AEP): (0.1% AEP): 100% (1% AEP): 100% (5%AEP): 0% 100% 0%

Flood Zones and Flood Defences




Figure A - Flood Zones

Flood Defence Source:	tidal	Upstream of Thames Barrier?	Yes
Flood Defence Type:	wall	Standard of Protection:	1000
Flood Warning Area	Tidal Thames from Woolwich Arsenal to Deptford Creek (100% Overlap)	Emergency Rest Centre	Halstow Primary School

Residual Tidal Flood Risk





Figure B - Maximum Flood Depth (Upriver Breach Assessment, MLWL 2100)

Site Name: Post office distribution centre/ Angerstein sites



Risk of Flooding from Surface Water (RoFSW)

Surface Water Source




Figure D Risk of Flooding from Surface Water (RoFSW)

Critical Drainage Area Group6_014 (100% Overlap)

Groundwater Source

Bedrock Geology	Thanet Sand Formation, Upper Chalk Formation	Superficial Geology	Alluvium - Clay, Silty, Peaty, Sandy, Kempton Park Gravel Formation
Bedrock Aquifer	Principal (100% Overlap), Secondary A (0% Overlap)	Superficial Aquifer	Secondary (undifferentiated) (99%
Designation		Designation	Overlap), Secondary A (1% Overlap)

Potential Groundwater Flooding Zone Zone B

Other Sources

Sewer Flooding	Internal Flood Incidents: 2	External Flood Incidents: 0	
(within 4 digit postcode)			
Artificial sources			

Site Name: Post office distribution centre/ Angerstein sites

Site Specific Recommendations

The site is located within Flood Zone 3 but is in an area that benefits from the Thames Tidal defences and is at residual risk of tidal flooding. More Vulnerable uses must be located on the first floor or above, with Less Vulnerable uses at ground level. Basements are not permitted on the site. The ROFSW map shows that site and surrounding area may be at high risk of surface water flooding. An assessment of the local surface water flow paths should be made during the development of the site design. the location of buildings and more vulnerable aspects of the development away from those areas at risk of surface water ponding. This site is suitable for water compatible open space development. Reference should be made to the Integrated Water Management Strategy for the area. Finished floor levels should be set at whichever level is higher: 300mm above the general ground level of the site or 600mm above the estimated sea level for a 1 in 200 year (0.5%AEP) event (including climate change). A number of flood resistance and resilience measures can be implemented into new developments to mitigate potential flooding. Guidance on resilience measures can be found in the document 'Improving the Flood Performance of New Buildings, Flood Resilient Construction' published by The Department for Communities and Local Government (CLG).

Potential overland flow paths from surface water should be determined and appropriate solutions proposed to minimise the impact of the development, whilst ensuring that flows are not diverted towards other properties elsewhere. Developers should consider using design for exceedance approaches by using urban areas and infrastructure to help manage local flooding. Flow paths should be assessed to inform the strategic location of SuDS and techniques to route flows around the edge of buildings. Careful consideration should be given to the use of fences and landscaping walls so as to prevent causing obstruction to flow routes.

Unobstructed safe access routes to and from the development should be provided. These should provide access to higher ground that is not at risk from tidal flooding. In the event of a breach in defences there is potential that dry routes to a safe location may be limited. The local area is covered by the 'Tidal Thames from Woolwich Arsenal to Deptford Creek' Environment Agency Flood Warning Area. A Flood Warning and Evacuation Plan (FWEP) must be prepared for the site, detailing how flood warning will be provided as well as how the safety of occupants and access to/from the development will be ensured. Further details of what should be included can be found in the Developer Guidance.

Reference to the SWMP Appendix D Figure D6 identifies that (prior to the completion of a site investigation to determine precise local conditions) infiltration of surface water into the ground is uncertain and potentially unsuitable for the site. Site investigations will be required prior to the development of a Drainage Strategy for the site. Development should utilise sustainable urban drainage systems (SUDS) unless there are practical reasons for not doing so. The site is located within the Group6_014 Critical Drainage Area. The potential development must not increase flood risk to other areas within the CDA. Where an increased risk exists, developers need to provide a Drainage Strategy to demonstrate how they intend to address this, by what methods, over what timeframe and how maintenance of such works would be funded over its lifetime. This should include a consideration of SuDS in line with the London Plan 5.13 and Local Plan Policies. Surface water run-off should be managed in line with Royal Greenwich's surface water management requirements, as set out in Chapter 4 of the Developer Guidance.

Summary

The site is located within Flood Zone 3, defended by Thames tidal defence, and has a residual risk of tidal flooding. More Vulnerable uses must be located on the first floor or above, with Less Vulnerable uses at ground level. Water compatible use would be suitable for this site. Tidal flood risk mitigation measures should be implemented into the site design to manage flood risk. It is recommended that effective surface water management measures are implemented, including careful site and building layout and the incorporation of SuDS, in order to reduce flooding both on the site and routing of flood water to other areas. Due to the extent of flood risk on the site, a flood warning and evacuation plan should be implemented to ensure access to and from the site. On this basis, it is likely that this site could pass the Exception Test.